

specificazioni

Tipo di penna Saldatore a gas

1. Portable, utilizzare ovunque e in qualsiasi momento
2. Nuova energia: puro butano

BST-100 Pen Type Gas Saldatore

Descrizione del prodotto

istruzione

1. Riempire con il gas dopo aver verificato che l'interruttore è stato spento.
2. Riempire di gas come da immagine 1. Portare il serbatoio del gas nel foro di riempimento e premere per riempire.
3. Ci vogliono circa 10 secondi per completare il riempimento. Attendere alcuni minuti per lasciare che il gas sia stabile prima dell'uso.
4. Si prega di premere leggermente la presa d'aria se c'è il rumore ZIZI dopo il riempimento.
5. Accendere l'interruttore finché non si sente il rumore ZIZI come nell'immagine 2.
6. Spostare in avanti l'anello di spegnimento come in figura 3.
7. Infilare la punta con l'accendino come l'immagine 4
8. La fiamma diventa più grande quando si sposta su '+', più piccola quando su '-'.
9. Inizia a usare quando la fiamma scompare e la punta diventa rossa. La fiamma non dovrebbe essere troppo grande in modo da prolungare la vita di servizio.
10. La lunghezza della fiamma è di circa 12 mm a 15 mm.

Importante: leggere le istruzioni prima dell'uso e seguire la sequenza operativa, in modo da evitare il pericolo di funzionamento improprio.

PRODUCT DISPLAY



PRODUCT SIZE



PRODUCT FEATURES



Warning

- ▶ Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- ▶ 1.Fill with gas after confirming the switch has been turned off.
- ▶ 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- ▶ 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- ▶ 4.Please press the air intake lightly if there is ZIZI noise after filling.
- ▶ 5.Turn on the switch until you hear ZIZI noise as picture 2.
- ▶ 6.Move the flameout ring forward as picture 3.
- ▶ 7.Fire the tip with lighter as picture 4
- ▶ 8.The flame become larger when move to '+',smaller when to '- '.
- ▶ 9.Begin to use when the flame disappears and the tip turns red.
The flame should not be too large so as to prolong the service life.
- ▶ 10.The length of the flame is about 12 mm to 15 mm.



picture 1



picture 2



picture 3



picture 4

PRODUCT PHOTOGRAPH





PRODUCT PACKAGING

WEIGHT:72G



FRONT



BACK