





- . 000000 000000 000000 000000 000000 0
- . 00000000 00000000 00000000 00000000 00000000 00000 0000 0
- . 000000 000000 0000000 0
- . 0000000000 0000 000 00000000 00000 0
- 0000000000 0000 0000 000000 0.

PRODUCT DISPLAY




For Mobile Phone Cellphone Tablet Screen Repair Cleaning Tools Cleaner Brush.

PRODUCT SIZE



Original plastic blade



Metal blade to be purchased separately

PRODUCT FEATURES




Use gestures when used



Non-slip silicone handle



Fixed blade



The blade is inserted from the top

Uses: scraping the ground or glass on the traces of decoration, such as chewing gum, paint, paint, cement, glue and other residual stains.

PRODUCT PHOTOGRAPH





WEIGHT:25G

