

Spezifikationen

Stift Typ Gas Lötkolben

1. Tragbar, überall und jederzeit einsetzbar
2. Neue Energie: reines Butan

BST-100 Stifttyp Gas Lötkolben

Produktbeschreibung

Anweisung

1. Füllen Sie das Gas nach der Bestätigung, dass der Schalter ausgeschaltet wurde.
2. Füllen Sie das Gas wie folgt ein: 1. Führen Sie den Gastank zur Füllöffnung und drücken Sie zum Füllen.
3. Es dauert ungefähr 10 Sekunden, um die Füllung zu vervollständigen. Warten Sie einige Minuten, bis das Gas vor Gebrauch stabil ist.
4. Bitte drücken Sie den Lufteinlass leicht, wenn nach dem Befüllen ZIZI-Geräusche auftreten.
5. Schalten Sie den Schalter ein, bis Sie ZIZI-Rauschen als Bild 2 hören.
6. Schieben Sie den Flammenring wie Bild 3 nach vorne.
7. Fire die Spitze mit Feuerzeug als Bild 4
8. Die Flamme wird größer, wenn Sie auf "+", kleiner auf "-" gehen.
9. Beginnt zu verwenden, wenn die Flamme verschwindet und die Spitze rot wird. Die Flamme sollte nicht zu groß sein, um die Lebensdauer zu verlängern.
10. Die Länge der Flamme beträgt etwa 12 mm bis 15 mm.

Wichtig: Bitte lesen Sie die Anweisungen vor der Verwendung und befolgen Sie die Bedienungsschritte, um die Gefahr eines unsachgemäßen Betriebs zu vermeiden.

PRODUCT DISPLAY



PRODUCT SIZE



PRODUCT FEATURES



Warning

- ▶ Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- ▶ 1.Fill with gas after confirming the switch has been turned off.
- ▶ 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- ▶ 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- ▶ 4.Please press the air intake lightly if there is ZIZI noise after filling.
- ▶ 5.Turn on the switch until you hear ZIZI noise as picture 2.
- ▶ 6.Move the flameout ring forward as picture 3.
- ▶ 7.Fire the tip with lighter as picture 4
- ▶ 8.The flame become larger when move to '+',smaller when to '- '.
- ▶ 9.Begin to use when the flame disappears and the tip turns red. The flame should not be too large so as to prolong the service life.
- ▶ 10.The length of the flame is about 12 mm to 15 mm.



picture 1



picture 2



picture 3



picture 4

PRODUCT PHOTOGRAPH





PRODUCT PACKAGING

WEIGHT:72G



FRONT



BACK