

000

0 00 00 00 00

- 1. 00 0000 00 00
- 2. 000 000 : 000 00

BST-100 0 00 00 00 00

00 00

00

- 1. 0000 0 0 000 00000.
- 2. 000 00 000 00000. 1. 00 000 00 000 00 000 00 0000.
- 3. 00 0000 0 10 00 00000. 0000 00 000 000 000 0 0 000000.
- 4. 00 0 ZIZI 000 000 00 0000 000 00000.
- 5. 00 20 00 ZIZI 000 00 000 0000 000.
- 6. 00 30 00 00 0000 000000.
- 7. 00 40 00 0000 00 000.
- 8. '+' 0 0000 000 000 '-' 0 00 00000.
- 9. 000 0000 00 000000 0000 0000000. 000 000 00 000 00 00000.
- 10. 000 000 0 12 mm 00 15 mm 000.

00 : 00000 00 00 000 00 00000 00000 0000 00 000 000000.

PRODUCT DISPLAY



PRODUCT SIZE



PRODUCT FEATURES



Warning

- ▶ Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- ▶ 1.Fill with gas after confirming the switch has been turned off.
- ▶ 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- ▶ 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- ▶ 4.Please press the air intake lightly if there is ZIZI noise after filling.
- ▶ 5.Turn on the switch until you hear ZIZI noise as picture 2.
- ▶ 6.Move the flameout ring forward as picture 3.
- ▶ 7.Fire the tip with lighter as picture 4
- ▶ 8.The flame become larger when move to '+',smaller when to '- '.
- ▶ 9.Begin to use when the flame disappears and the tip turns red.
The flame should not be too large so as to prolong the service life.
- ▶ 10.The length of the flame is about 12 mm to 15 mm.



picture 1



picture 2



picture 3



picture 4

PRODUCT PHOTOGRAPH





PRODUCT PACKAGING

WEIGHT:72G



FRONT



BACK