#### 

BST-100

#### 

- 10.



## PRODUCT SIZE



## PRODUCT FEATURES





# 🚹 Warning

Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation.



## **Instruction**

- 1. Fill with gas after confirming the switch has been turned off.
- 2. Fill with gas as picture 1. Lead the gas tank to the filling hole and press to fill.
- 3. It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- 4.Please press the air intake lightly if there is ZIZI noise after filling.
- 5. Turn on the switch until you hear ZIZI noise as picture 2.
- 6.Move the flameout ring forward as picture 3.
- 7. Fire the tip with lighter as picture 4
- 8. The flame become larger when move to '+', smaller when to '- '.
- 9.Begin to use when the flame disappears and the tip turns red. The flame should not be too large so as to prolong the service life.
- 10. The length of the flame is about 12 mm to 15 mm.









picture 2

picture 3

picture 4





#### WEIGHT:72G



**FRONT** 

**BACK**