

Характеристики

Печное газовое паяльное жало

- 1.Портабельный, использовать в любом месте в любое время
2. Новая энергия: чистый бутан

Газовый паяльник BST-100

описание продукта

инструкция

1. Заправьте газ после подтверждения отключения выключателя.
2. Заполните газом как изображение. 1. Залейте газовый баллон в заполняющее отверстие и нажмите, чтобы заполнить.
- 3.If принимает около 10 секунд для того чтобы завершить заполнение. Подождите несколько минут, чтобы газ был устойчивым перед использованием.
- 4.Пожалуйста, нажмите воздухозаборник слегка, если после наполнения есть шум ZIZI.
5. Включите переключатель, пока не услышите шум ZIZI, как изображение 2.
6. Выдвиньте кольцо пламени вперед как изображение 3.
7. Закрепите наконечник с зажигалкой как изображение 4
8. Пламя становится больше при переходе на «+», меньше, когда на «-».
- 9.Begin использовать, когда пламя исчезает, и кончик становится красным. Пламя не должно быть слишком большим, чтобы продлить срок службы.
10. Длина пламени составляет от 12 мм до 15 мм.

Важное замечание. Пожалуйста, прочитайте инструкцию перед использованием и следуйте последовательности действий, чтобы избежать опасности для неправильной работы.

PRODUCT DISPLAY



PRODUCT SIZE



PRODUCT FEATURES



Warning

- ▶ Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- ▶ 1.Fill with gas after confirming the switch has been turned off.
- ▶ 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- ▶ 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- ▶ 4.Please press the air intake lightly if there is ZIZI noise after filling.
- ▶ 5.Turn on the switch until you hear ZIZI noise as picture 2.
- ▶ 6.Move the flameout ring forward as picture 3.
- ▶ 7.Fire the tip with lighter as picture 4
- ▶ 8.The flame become larger when move to '+',smaller when to '- '.
- ▶ 9.Begin to use when the flame disappears and the tip turns red.
The flame should not be too large so as to prolong the service life.
- ▶ 10.The length of the flame is about 12 mm to 15 mm.



picture 1



picture 2



picture 3



picture 4

PRODUCT PHOTOGRAPH





PRODUCT PACKAGING

WEIGHT:72G



FRONT



BACK