□□□

□ □□ □□ □□ □□
1. □□ □□□□ □□ □□
2. □□□ □□□ : □□□ □□

BST-100 □ □□ □□ □□ □□

□□ □□

□□
1. □□□□ □ □ □□□ □□□□□.
2. □□□ □□ □□□ □□□□□. 1. □□ □□□ □□ □□□ □□ □□□ □□ □□□□.
3. □□ □□□□ □ 10 □□ □□□□□. □□□□ □□ □□□ □□□ □□□ □ □ □□□□□□.
4. □□ □ ZIZI □□□ □□□ □□ □□□□ □□□ □□□□□.
5. □□ 2□ □□ ZIZI □□□ □□ □□□ □□□□ □□□.
6. □□ 3□ □□ □□ □□□□ □□□□□□.
7. □□ 4□ □□ □□□□ □□ □□□.
8. '+'□ □□□□ □□□ □□□ '-'□ □□ □□□□□.
9. □□□ □□□□ □□ □□□□□ □□□□ □□□□□□. □□□ □□□ □□ □□□ □□ □□□□□.
10. □□□ □□□ □ 12 mm□□ 15 mm□□□.

□□ : □□□□ □□ □□ □□□ □□ □□□□ □□□□ □□□ □□ □□□ □□□□□.

PRODUCT DISPLAY

PRODUCT SIZE

PRODUCT FEATURES

Warning

- Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- 1.Fill with gas after confirming the switch has been turned off.
- 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- 4.Please press the air intake lightly if there is ZIZI noise after filling.
- 5.Turn on the switch until you hear ZIZI noise as picture 2.
- 6.Move the flameout ring forward as picture 3.
- 7.Fire the tip with lighter as picture 4
- 8.The flame become larger when move to '+',smaller when to '- '.
- 9.Begin to use when the flame disappears and the tip turns red. The flame should not be too large so as to prolong the service life.
- 10.The length of the flame is about 12 mm to 15 mm.

picture 1

picture 2

picture 3

picture 4

PRODUCT PHOTOGRAPH

BEST
倍思特
BST-100
ON
OFF

PRODUCT PACKAGING

WEIGHT:72G

78MM

190MM

FRONT

BACK