[illegible]

[illegible] Soldering Iron
1. [illegible]
2. [illegible]: [illegible]

BST-100 [illegible]

[illegible]

[illegible]
1. [illegible]
2. [illegible] 1. [illegible]
3. [illegible] 10 [illegible] [illegible]
4. [illegible] [illegible] [illegible] ZIZI [illegible]
5. [illegible] ZIZI [illegible] 2
6. [illegible] 3
7. [illegible] 4
[illegible] '+' [illegible] '-'
9. [illegible]
[illegible]
10. [illegible] 12 [illegible]. [illegible] 15 [illegible].

[illegible]:
[illegible]
[illegible]

PRODUCT DISPLAY

PRODUCT SIZE

PRODUCT FEATURES

Warning

- Please read the instruction before using and follow the operation sequence, so as to avoid the danger for improper operation .

Instruction

- 1.Fill with gas after confirming the switch has been turned off.
- 2.Fill with gas as picture 1.Lead the gas tank to the filling hole and press to fill.
- 3.It takes about 10 seconds to complete the filling. Wait several minutes to let the gas be steady before use.
- 4.Please press the air intake lightly if there is ZIZI noise after filling.
- 5.Turn on the switch until you hear ZIZI noise as picture 2.
- 6.Move the flameout ring forward as picture 3.
- 7.Fire the tip with lighter as picture 4
- 8.The flame become larger when move to '+',smaller when to '- '.
- 9.Begin to use when the flame disappears and the tip turns red. The flame should not be too large so as to prolong the service life.
- 10.The length of the flame is about 12 mm to 15 mm.

picture 1

picture 2

picture 3

picture 4

PRODUCT PHOTOGRAPH

BEST
倍思特
BST-100
ON
OFF

PRODUCT PACKAGING

WEIGHT:72G

78MM

190MM

FRONT

BACK